ProCom Technologies, LLC

TVA-50 Voice Mail "In Mailbox Guide Basic version"

Access by dialing ext. 200, or by pressing the message button. (note the message button only works when the light is on!)

Main Menu:

Options 1-6

Press 1, To receive messages

Pressing 1 = new messages

Pressing 2 = old messages

Pressing 3 = deleted messages

Press 2, To send a message

Enter the mailbox number of message to record and send

Press 3, To Manage your mailbox

Pressing 1 = personal greetings

Pressing 2 = password

Pressing 3 = owners name

Pressing 4 = group distribution lists

Pressing 5 = caller id name and number

Pressing 6 = remote call fwd to CO setting

Pressing 8 = change personal custom service

Press 4. To set auto attendant status

Pressing 1 = To set call transfer status

Pressing 2 = To set covering Ext.

Pressing 3 = To set message reception mode

Pressing 4 = Incomplete handling for No Answer

Pressing 5 = Incomplete handling for Busy

Press 5, To set message waiting notification

Pressing 1 = To change the message lamp status

Pressing 2 = To change a device status

Pressing 3 = To change the telephone or Beeper numbers

Press 6, To set other features

Pressing 3 = To set Fwd settings

Pressing 4 = To set Timed reminder

The "#" codes

#1 = shortcut to name directory

#2 = Shortcut to custom service menu

#6 = To Mailbox user level

#6* = Access to Mailbox Subscriber

#8 = To extension user level

#9 = hang up and good bye